


Demonstration firmware for NUCLEO-G431RB enabling STSW-IFAPGUI on X-NUCLEO-OUT12A1 and X-NUCLEO-OUT14A1 expansion boards



Features

- Full control of the X-NUCLEO-OUT12A1 and X-NUCLEO-OUT14A1 expansion boards via the STSW-IFAPGUI graphical user interface
- Control of:
 - output channel switching frequency and duty cycle configuration
 - visualization of diagnostic signals (power good and common over-temperature/communication error diagnostics)
 - both Regular Mode and Daisy Chain Mode management

Description

The STSW-OUT12G4 firmware runs on the NUCLEO-G431RB development board and allows controlling the X-NUCLEO-OUT12A1 or X-NUCLEO-OUT14A1 expansion boards using the STSW-IFAPGUI graphical user interface.

The STSW-OUT12G4 contains the software routines that enable the USB-based communication between the NUCLEO-G431RB and the system where the STSW-IFAPGUI runs, and the control of the X-NUCLEO-OUT12A1 or X-NUCLEO-OUT14A1.

The firmware can control a single expansion board or two stacked X-NUCLEO-OUT12A1 (or X-NUCLEO-OUT14A1) configured in parallel independent or daisy chaining mode.

The STSW-IFAPGUI is based on a common engine and several plug-ins designed to communicate through the USB connection with the application layer running on the NUCLEO-G431RB development board stacked with the expansion board.

Product summary	
Demonstration firmware for NUCLEO-G431RB enabling STSWIFAPGUI on X-NUCLEO-OUT12A1 and X-NUCLEO-OUT14A1 expansion boards	STSW-OUT12G4
Industrial digital output expansion board based on ISO808A for STM32 Nucleo	X-NUCLEO-OUT12A1
Industrial digital output expansion board based on ISO808A-1 for STM32 Nucleo	X-NUCLEO-OUT14A1
STM32 Nucleo-64 development board with STM32G431RB MCU, supports Arduino and ST morpho connectivity	NUCLEO-G431RB
Graphical user interface for the industrial IPS and IO-Link transceiver evaluation boards based on STM32 Nucleo	STSW-IFAPGUI
Applications	Industrial Safety Industrial Tools

1 Control of the expansion board (single or dual) by IFAPGUI

1.1 System identification


- Step 1.** Stack the expansion system (single X-NUCLEO-OUT12A1/X-NUCLEO-OUT14A1, or combined as parallel independent / daisy chain) through the Arduino connectors on the NUCLEO-G431RB board flashed with the STSW-OUT12G4 firmware.
- Step 2.** Connect the complete system (expansion + Nucleo) to your PC or laptop USB port through a micro-USB cable.
The STM32 is supplied via USB (3.3 V) and the flashed firmware starts running.
Press the black button on the NUCLEO-G431RB board to reset the firmware.
- Step 3.** Launch the STSW-IFAPGUI.
When the application starts, the firmware running on the STM32 is automatically detected and a COM port is opened for communication.

Figure 1. STSW-IFAPGUI COM port opened



- Step 4.** Click on the GUI STM32 Nucleo icon after it turns blue (it remains green until the firmware identification is complete).
A popup window appears to choose the proper system configuration.

Figure 2. System configuration selection panel




Ignore option [1] (specifically dedicated to ISO808 family driven by parallel interface, instead of SPI interface) and select option [2] (for Single or Parallel Independent) or [3] (Daisy Chaining) according to your system configuration.

1.2 Regular mode (Parallel Independent)

This mode allows the control of a single expansion board or the control of two stacked expansion boards but not configured in daisy chaining.


Step 1. Select [2] **PARALLEL INDEPENDENT MODE** and the STSW-IFAPGUI appears on the screen.

Figure 3. STSW-IFAPGUI main control panel BOARD 0




If present in your configuration, the second board panel is enabled (see next figure).

Figure 4. STSW-IFAPGUI main control panel BOARD 1



- Step 2.** If more than one board is present in your system, you can select the proper board to send the commands to: use the tab BOARD 0 | BOARD 1 in the top left side of the GUI to select the board. Then use the dedicated section of the GUI for the desired channel of ISO808A (or ISO808A-1) to:
- manage channel steady state (the left part in each channel section)
 - manage channel PWM settings (the right part in each channel section)
- Use the bottom left side of the GUI to:
- enable/disable outputs, properly setting the Output Enable pin
 - enable/disable and reset diagnostic pin and Power Good polling activities
 - reset all channel features to OFF state for the selected board
- Step 3.** Connect the load and supply the power stage of the X-NUCLEO-OUT12A1 (or X-NUCLEO-OUT14A1) with a 24 V rail via the CN1 connector.
- Step 4.** Select the desired switching frequency and duty cycle of the desired output channel through the [Pulse Width Modulation] controls in the right part of desired channel section.
- Step 5.** The desired output channel steady state can be activated/deactivated by clicking on the [ON/OFF] buttons in the left part of the desired channel section in the [STEADY STATE] sub-section.
- Step 6.** Click on the [START] button in the [Thermal shutdown or Internal Communication Error Status Pin Check] area on the bottom left side of the GUI to monitor the on/off status on the FAULT pin on ISO808A (or ISO808A-1).
You can stop monitoring the fault status by clicking on the [STOP] button in the same section. Press the [RESET] button to reset the fault status.
- Step 7.** Click on [Enable] button in Output Enable Pin section to drive the output pins. Click on [Disable] in the same section to turn off all output pins.
- Step 8.** Click on [RESET] button in Command Reset section to reset any channel setting and also the diagnostic pins status monitoring.

Figure 5. STSW-IFAPGUI in action



1.3 Daisy Chain mode

This mode is specifically designed for the system configuration with two stacked expansion boards configured in daisy chaining.

Step 1. Select [3] DAISY CHAIN MODE and the STSW-IFAPGUI appears on the screen.

Figure 6. STSW-IFAPGUI main control panel Daisy Chain BOARD 0





Figure 7. STSW-IFAPGUI main control panel Daisy Chain BOARD 1



Step 2. In Daisy Chain the system must be composed of two boards: you can select the proper board, whose status you want to change, using the tab **BOARD 0 | BOARD 1** in the top left side of the GUI.

Note: *output stage is 16-bit wide, so any change in input state must be sent to the system with a 2-bytes SPI write operation.*

After selecting the board to modify, use the dedicated section of the GUI for the desired channel of ISO808A (or ISO808A-1) to:

- manage channel steady state (the left part in each channel section)
- manage channel PWM settings (the right part in each channel section)

Use the bottom left side of the GUI to:

- enable/disable outputs, properly setting the Output Enable pin (common for the two boards)
- enable/disable and reset diagnostic pin and Power Good polling activities
- reset all channel features to OFF state for the whole system

Step 3. Connect the load and supply the power stage of the X-NUCLEO-OUT12A1 (or X-NUCLEO-OUT14A1) with a 24 V rail via the CN1 connector.

Step 4. Select the desired switching frequency and duty cycle of the desired output channel through the [Pulse Width Modulation] controls in the right part of desired channel section


Step 5. The desired output channel steady state can be activated/deactivated by clicking on the [ON/OFF] buttons in the left part of the desired channel section in [STEADY STATE] sub-section.

Step 6. Click on the [START] button in [Thermal shutdown or Internal Communication Error Status Pin Check] area in the bottom left side of the GUI to monitor the on/off status on the FAULT pin on ISO808A (or ISO808A-1). You can stop monitoring the fault status by clicking on the [STOP] button in the same section. Press [RESET] button to reset the fault status.

Step 7. Click on [Enable] button in **Output Enable Pin** section to drive the output pins. Click on [Disable] in the same section to turn off all output pins

Step 8. Click on [RESET] button in **Command Reset** section to reset any channel setting and the diagnostic pins status monitoring.

Figure 8. STSW-IFAPGUI in action



2 Control of the expansion board (single or dual) by command line

There are three application scenarios, respectively based on:

- One board with the default on-board switches and resistors configuration of X-NUCLEO-OUT12A1 (or X-NUCLEO-OUT14A1)
- Two boards X-NUCLEO-OUT12A1 (or X-NUCLEO-OUT14A1) configured in Regular mode (parallel independent boards)
- Two boards X-NUCLEO-OUT12A1 (or X-NUCLEO-OUT14A1) configured in Daisy Chain mode

Step 1. Plug the X-NUCLEO-OUT12A1 or X-NUCLEO-OUT14A1 expansion board(s) on top of the NUCLEO-G431RB board, flashed with the STSW-OUT12G4 firmware, through the Arduino connectors.

Step 2. Connect the stacked boards to your PC or laptop USB port through a micro-USB cable. The STM32 is supplied via USB (3.3 V) and the flashed firmware starts running.

Press the black button on the NUCLEO-G431RB board to reset the firmware.

Step 3. Launch the serial communication terminal application (TeraTerm in our notes).

When the application starts, the serial communication must be configured as follows:

Figure 9. Tera Term: select serial communication method




Figure 10. Tera Term: Setup / Terminal...






Figure 11. Tera Term: Setup / Serial port...



Step 4. Press Enter and then type 'h' for help:

Figure 12. CLI help



```

COM17 - Tera Term VT
File Edit Setup Control Window Help
ST Switch Console Firmware U01.00.00 [Mar 10 2023 14:21:23] for chip 808
type 'h' to get some help
h
-----
Welcome to ST Switch Console help utility!
You're running firmware ST Switch Console Firmware U01.00.00 [Mar 10 2023 14:21:23] for chip 808
Two Apis are implemented in this version:
- The Switch Api
- The System Api
To execute a switch command, type 'W' followed by a command id
and then param1 param2 param3 param4 if there are parameters
e.g. type 'W0 0 808 1 1' to initialise one 808 device in Parallel independent mode
e.g. type 'W0 0 808 1 2' to initialise one 808 device in Daisy chain mode
To execute a system command, type 'S' followed by a command id
e.g. type 'S1' to get the FW version
To get more help regarding switch commands, just type 'W'
To get more help regarding system commands, just type 'S'
-----

```


Step 5. Type 'w?' for a list of commands available:


Figure 13. Command list

```

COM17 - Tera Term VT
File Edit Setup Control Window Help
ST Switch Console Firmware V01.00.00 [Mar 10 2023 14:21:23] for chip 808
type 'h' to get some help
w?
Switch API commands list:
Id: 0 IPS_SWITCH_API_INIT
w0 Instance<1B> ChipId<2B> NbDevices<1B> opMode<1B> -> Output: status<4B>
Id: 1 IPS_SWITCH_API_DEINIT
w1 Instance<1B> -> Output: status<4B>
Id: 2 IPS_SWITCH_API_READ_ID
w2 Instance<1B> -> Output: status<6B>
Id: 3 IPS_SWITCH_API_GET_FW_VERSION
w3 Instance<1B> -> Output: status<8B>
Id: 4 IPS_SWITCH_API_GET_CAPABILITIES
w4 Instance<1B> -> Output: status<5B>
Id: 5 IPS_SWITCH_API_GET_FAULT_STATUS
w5 Instance<1B> -> Output: status<5B>
Id: 6 IPS_SWITCH_API_GET_CHANNEL_STATUS
w6 Instance<1B> ChanId<1B> -> Output: status<5B>
Id: 7 IPS_SWITCH_API_SET_CHANNEL_STATUS
w7 Instance<1B> ChanId<1B> ChanStatus<1B> -> Output: status<4B>
Id: 8 IPS_SWITCH_API_GET_ALL_CHANNEL_STATUS
w8 Instance<1B> -> Output: status<5B>
Id: 9 IPS_SWITCH_API_SET_ALL_CHANNEL_STATUS
w9 Instance<1B> ChanBitmap<1B> -> Output: status<4B>
Id: 10 IPS_SWITCH_API_GET_CHANNEL_FREQ
w10 Instance<1B> ChanId<1B> -> Output: status<6B>
Id: 11 IPS_SWITCH_API_SET_CHANNEL_FREQ
w11 Instance<1B> ChanId<1B> Freq<2B> -> Output: status<4B>
Id: 12 IPS_SWITCH_API_GET_CHANNEL_DC
w12 Instance<1B> ChanId<1B> -> Output: status<5B>
Id: 13 IPS_SWITCH_API_SET_CHANNEL_DC
w13 Instance<1B> ChanId<1B> DutyCycle<1B> -> Output: status<4B>
Id: 14 IPS_SWITCH_API_GET_PWM_ENABLE
w14 Instance<1B> ChanId<1B> -> Output: status<5B>
Id: 15 IPS_SWITCH_API_SET_PWM_ENABLE
w15 Instance<1B> ChanId<1B> PwmEnable<1B> -> Output: status<4B>
Id: 17 IPS_SWITCH_API_GET_CTRL_PIN_STATUS
w17 Instance<1B> CtrlPinId<1B> -> Output: status<5B>
Id: 18 IPS_SWITCH_API_SET_CTRL_PIN_STATUS
w18 Instance<1B> CtrlPinId<1B> CtrlPinStatus<1B> -> Output: status<4B>
Id: 20 IPS_SWITCH_API_GETFAULTREGISTER
w20 Instance<1B> -> Output: status<5B>
Id: 21 IPS_SWITCH_API_QUEUECHANNELSTATUS
w21 Instance<1B> ChanId<1B> ChanStatus<1B> -> Output: status<4B>
Id: 22 IPS_SWITCH_API_QUEUEALLCHANNELSTATUS
w22 Instance<1B> ChanBitmap<1B> -> Output: status<4B>
Id: 23 IPS_SWITCH_API_SENDQUEUEDCHANNELSTATUS
w23 Instance<1B> -> Output: status<4B>
Id: 24 IPS_SWITCH_API_GETFAULTREGISTER_DAIYCHAIN
w24 Instance<1B> -> Output: status<6B>
    
```

- Step 6.** Initialize the device as first action using **w0** command, in Regular mode or in Daisy Chain mode, according with current hardware configuration:


Figure 14. Device init in Regular mode



```

COM17 - Tera Term VT
File Edit Setup Control Window Help
ST Switch Console Firmware U01.00.00 [Mar 10 2023 14:21:23] for chip 808
type 'h' to get some help
w0 0 808 1 1
0
  
```

Figure 15. Device init in Daisy Chain mode



```

COM17 - Tera Term VT
File Edit Setup Control Window Help
ST Switch Console Firmware U01.00.00 [Mar 10 2023 14:21:23] for chip 808
type 'h' to get some help
w0 0 808 1 2
0
  
```

- Step 7.** Continue to interact with the device using commands from the available command list (see above).

Note:

- *Commands ID 7, 9 and 20 are available only in Regular mode*
- *Commands ID 21, 22, 23 and 24 are available only in Daisy Chain mode*

Revision history

Table 1. Document revision history

Date	Revision	Changes
08-May-2023	1	Initial release.

IMPORTANT NOTICE – READ CAREFULLY

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgment.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers’ products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2023 STMicroelectronics – All rights reserved