



EV-VNH90xxAQ motor driver**Introduction**


This document describes the specifications for the EV-VNH90xxAQ easy board, which can be connected to the EV-SPC582B to create a full bridge motor driver evaluation tool intended for a wide range of automotive applications. To simplify the evaluation of VNH90xxAQ devices, a GUI has been developed to facilitate the management of VNH90xxAQ inputs, monitor H-Bridge status, and provide current sensing and fault diagnostic feedback. Collectively, this solution provides a powerful and flexible tool for managing motor operations.

1 Quick start

The EV-VNH90xxAQ evaluation board simplifies the integration of ST VIPower M0-9 DC motor drivers into your prototype circuitry. This preassembled board includes the VNH90xxAQ, and the essential electrical components as recommended in the device datasheet. This setup allows for direct connections to the load, power supply, and microcontroller, eliminating the need for additional external component design and connections.

When used with the EV-SPC582B board (available on st.com), it forms a comprehensive evaluation tool for assessing the performance of EV-VNH90xxAQ motor drivers

Figure 1. EV-VNH90xxAQ board




1.1 Getting started

Follow the sequence below to configure the system and launch the application:

1. Check the jumpers position of the EV-SPC582B board in the user manual (available on www.st.com)
2. Connect the EV-SPC582B board to a PC through USB cable "type A to mini B"
3. If the EV-SPC582B board must be programmed execute this step otherwise skip it:
 - Download firmware STSW-EV-VNH9xxx (available on www.st.com) and program the board as described in [Section 2.3: FW Download](#).
4. Disconnect USB cable
5. Stack EV-VNH9030AQ on top of EV-SPC582B (as shown in chapter 2.4)
6. Install the GUI as described on STSW-EV-VNH9xxx (available on www.st.com)
7. Power supply (as shown in [Section 2.4: System connections](#))
 - a. Supply MCU as described in the EV-SPC582B user manual
 - b. Apply $V_{CC} < V_{CCmax.}$ between V_{BAT} and P_{GND} in the EV-VNH90xxAQ board
8. Connect using USB cable PC <-> EV-SPC582B (as shown on [Section 2.4: System connections](#))
9. Run GUI (see features in [Section 2.5: RUN GUI \(graphical user interface\)](#))

2 Hardware, schematic

Figure 2. VNH90xxAQ evaluation board schematic



2.1 VNH90xxAQ product Family

2.1.1 Features

Type	$R_{DS(on)}$, per leg	I_{OUT}
VNH9030AQ	30 m Ω	35 A
VNH9045AQ	45 m Ω	23 A
VNH9090AQ	82 m Ω	15 A

- AEC-Q100 qualified
- ISO 26262 ready
- CMOS compatible inputs
- Undervoltage shutdown
- Overvoltage clamp
- Thermal shutdown
- Cross-conduction protection
- Current and power limitation
- Very low standby power consumption
- Protection against loss of ground and loss of V_{CC}
- PWM operation up to 25 kHz
- Multisense monitoring functions
 - Analog motor current feedback
 - Chip temperature monitoring
- Multisense diagnostic functions
 - Output short to ground detection
 - Thermal shutdown indication
 - OFF-state open-load detection
 - High-side power limitation indication
 - Low-side overcurrent shutdown indication
 - Output short to V_{CC} detection
- Output protected against short to ground and short to V_{CC}
- Standby mode
- Half bridge operation
- Pin to pin compatibility among the whole family

2.1.2 Application


- Motor control automotive applications supplied by 12 V board-net

2.3 FW Download

EV-SPC582B board configuration

1. Put jumper on JP3 and JP4 on the right side (5 V)
2. Connect USB cable for board communication and programming.


Figure 4. EV-SPC582B



2.3.1 UDE driver installation

Download tool: Go to <https://www.pls-mc.com/service/downloads/download-spc5-udestk/>

Figure 5. Download tool shema




Click, download, and install the UDE tool SPC5-UDESTK 2021.05 64-bit version

2.3.2 Driver installation check

If driver installation is finished, connect the USB cable to the EV-SPC582B and open the device manager in Windows OS:

Figure 6. Driver installation




This two PLS controllers must have been recognized if everything went well.

2.3.3 Programming EV-SPC582B (new workspace creation)


1. Plug USB cable to SPC582B
2. Execute UDE STK tool
3. Create a new workspace: go to File/New workspace
4. Configure the workspace: Click on default

Figure 7. New workspace creation



5. Configure the workspace:
 - Select use a default target configuration
 - Select STMicroelectronics chorus 1M SPC58 discovery starter kit
6. Click finish


Figure 8. Programming



2.3.4 New workspace creation

1. Configure the workspace:
 - Additional filter: Discovery kits
 - Select STMicroelectronics chorus 1M SPC58 discovery starter kit
2. Click OK to finish


Figure 9. New workspace creation



2.3.5 Check connection

If the workspace was correctly created and the USB channel recognized, a success message in the messages box should appear.


Figure 10. Check connection



2.3.6 Load .elf file


1. Click on File/Load program
2. Browse and select the .elf file to be loaded
Figure x: Elf file

Figure 11. Load .Elf



3. Click OK


Figure 12. Click OK



2.3.7 Program .elf file

1. Click program all


Figure 13. Program .elf



2.3.8 Check the programming result

1. If the board was programmed correctly a success message appears
2. Press exit and save workspace changes for the future use

Figure 14. Check



2.4 System connections


To ensure a successful launch of the GUI, please verify the following connections:

1. Ensure the USB connection between the PC and the EV-SPC582B is secure
2. Confirm that the 12 V power supply is properly connected between V_{CC} and GND connectors on the EV-VNH90xxAQ
3. Verify that the load is connected to the OUTA and OUTB connectors on the EV-VNH9xxx.

2.5 RUN GUI (graphical user interface)

For detailed information, please refer to STSW-EV-VNH9xxx (available on www.st.com).


Figure 15. Clockwise



2.5.1 Check connection

After checking the connection and the power supply is ON check on the status bar below:

Figure 16. Check connection




If the boards are connected and the communication is running well, this bar shows connection status (green light), GUI revision, and firmware revision.

2.5.2 MAIN control and settings

This section of the GUI enables users to manage various aspects of motor operation. Users can control the direction of load rotation by toggling between "forward" and "reverse," which adjusts the motor's rotational direction (clockwise or counterclockwise). They can also apply a braking condition by selecting either "Brake to VCC" or "Brake to GND."

Furthermore, users are able to drive each PowerMOSFET independently, as well as set the device to an off state or standby mode.

Figure 17. M09 H-Bridge




Here is an illustrative example:

1. Configure parameters: Set "Kfactor" and "RSense" in the "Current measurement" section.
2. Select rotation flag: Choose "Forward" or "Reverse" to drive the device in a clockwise or counterclockwise direction.
3. Set PWM parameters: Define the PWM frequency and duty cycle to control the low side switches.
4. Start PWM: Click on "Start PWM" to send the configuration to the EV-SPC582B.
5. Adjust States: Modify "SEL0" and "SEL1" states in the "Current measurement" section to monitor LegA or LegB.
6. Monitor activity: Click "Graph" under the "Current measurement" section to observe the H-Bridge current sense activity.

In "H-Bridge status" the user can monitor the device's working state as it is shown in the following:

Brake to GND

Figure 18. Brake to GND




Inputs configuration:

- INA = INB = L
- PWM = H

Note: Setting the pin SEL1 = 1 and SEL0 = 0 (SEL1 = 1 and SEL0 = 1) it is possible to keep one leg in HiZ for half bridge configuration and diagnostic.

Brake to VCC

Figure 19. Brake to VCC




Inputs configuration:

- INA = INB = H
- PWM = L

Note: Setting the pin SEL1 = 1 and SEL0 = 0 (SEL1 = 1 and SEL0 = 1) it is possible to keep one leg in HiZ for half bridge configuration and diagnostic.

Clockwise

Figure 20. Clockwise




Inputs configuration

- INA = H
- INB = L
- PWM switching

Note: Correctly setting selectors it is possible to monitor current flowing through HSA.

Counterclockwise

Figure 21. Counterclockwise



Inputs configuration

- INA = L
- INB = H
- PWM switching

Revision history

Table 1. Document revision history

Date	Revision	Changes
17-Dec-2024	1	Initial release.

Contents

1	Quick start	2
1.1	Getting started	2
2	Hardware, schematic	3
2.1	VNH90xxAQ product Family	4
2.1.1	Features	4
2.1.2	Application	4
2.1.3	Description	5
2.2	Easy board connectors	5
2.3	FW Download	6
2.3.1	UDE driver installation	7
2.3.2	Driver installation check	7
2.3.3	Programming EV-SPC582B (new workspace creation)	8
2.3.4	New workspace creation	9
2.3.5	Check connection	10
2.3.6	Load .elf file	11
2.3.7	Program .elf file	11
2.3.8	Check the programming result	12
2.4	System connections	12
2.5	RUN GUI (graphical user interface)	13
2.5.1	Check connection	13
2.5.2	MAIN control and settings	14
	Revision history	19

List of figures

Figure 1.	EV-VNH90xxAQ board	2
Figure 2.	VNH90xxAQ evaluation board schematic	3
Figure 3.	Connectors	5
Figure 4.	EV-SPC582B	6
Figure 5.	Download tool shema	7
Figure 6.	Driver installation	7
Figure 7.	New workspace creation	8
Figure 8.	Programming	8
Figure 9.	New workspace creation	9
Figure 10.	Check connection	10
Figure 11.	Load .Elf	11
Figure 12.	Click OK	11
Figure 13.	Program .elf	11
Figure 14.	Check	12
Figure 15.	Clockwise	13
Figure 16.	Check connection	13
Figure 17.	M09 H-Bridge	14
Figure 18.	Brake to GND	15
Figure 19.	Brake to VCC	16
Figure 20.	Clockwise	17
Figure 21.	Counterclockwise	18

IMPORTANT NOTICE – READ CAREFULLY

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgment.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers’ products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2024 STMicroelectronics – All rights reserved